

IMPORTANT SERVICE NOTE

To Destination Install Technician

This appliance has been serviced and secured using a LITKIT® Pro™ Washing Machine Drum Stabilization Kit

Before hooking up, remove top of machine.

Note: Some front load machines must be accessed by removing the rear panel. (LG models and the GE Adora among others).

Look inside and see two inflated air bags. One on each side of the drum and one 3 inch corrugated cell block **(optional)** installed between the metal cross brace and the drum of the machine. Block installed ___Yes ___No

ORIGIN SERVICE TECH: In the space above - please check if the optional corrugated cell block was installed.

To deflate, simply pull the black rubber tab off of each inlet valve at the top of each bag.

Depress the star shaped stem and the bags will instantly deflate. You may have to apply pressure by hand to the bag itself while pressing down on the stem to get all of the air out enabling safe removal.

Save bags and corrugated block for re-use.

IMPORTANT SERVICE NOTE

To Destination Install Technician

This appliance has been serviced and secured using a LITKIT® Pro™ Washing Machine Drum Stabilization Kit

Before hooking up, remove top of machine.

Note: Some front load machines must be accessed by removing the rear panel. (LG models and the GE Adora among others).

Look inside and see two inflated air bags. One on each side of the drum and one 3 inch corrugated cell block **(optional)** installed between the metal cross brace and the drum of the machine. Block installed ___Yes ___No

ORIGIN SERVICE TECH: In the space above - please check if the optional corrugated cell block was installed.

To deflate, simply pull the black rubber tab off of each inlet valve at the top of each bag.

Depress the star shaped stem and the bags will instantly deflate. You may have to apply pressure by hand to the bag itself while pressing down on the stem to get all of the air out enabling safe removal.

Save bags and corrugated block for re-use.